


NRV 4/3 Directional Control Valve

Dimension sketch



| Ordering code | Pressure medium | Max. flow L / min. | Working pressure | Connection | Temperature |
|---------------|-----------------|--------------------|------------------|--------------|---------------|
| NRV 4/3-x1-x2 | Oil or water | 10 | 200 bar | 1/4" or 3/8" | +1° to +60° C |

Please state position **x1** and connection **x2** when ordering:

x1: Spring centred: F **x2:** 1/4" BSP
x1: Position lock : P **x2:** 3/8" BSP

How to order:
 NRV 4/3- **x1** - **x2**

x1: Spring centred : F
x2: Connection : 3/8" BSP

Ordering code: **NRV 4/3 - F - 3/8" BSP**

Venligst oplys position **x1** og tilslutning **x2** ved ordre:

x1: Fjedercentret : F **x2:** 1/4" BSP
x1: Positions-lås : P **x2:** 3/8" BSP

Eksempel på ordre:
 NRV 4/3- **x1** - **x2**

x1: Fjedercentret : F
x2: Tilslutning : 3/8" BSP

Ordre kode: **NRV 4/3 - F - 3/8" BSP**